

INSTRUCTIONS FOR DRY ADHESIVE BONDING

Step 1: Prepare surface

The surface and the room should have a temperature of at least 10 degrees. If the surface has recently been painted, make sure that the varnish is completely hard and dry.

Clean and defat the surface thoroughly. There should be no remains of wax or polish on the surface.

Our tip: If there is a wax layer on the surface, use silicon remover.

Step 2: Cut decor

Cut the decors thoroughly before fixation. If the decor consists of several parts, it is easier to cut them separately.

Put the sticker on a level surface and flatten out the sticker.

Hold the sticker up to the model and fixate it with tape in the middle once the sticker is in the right position.

Step 3: Remove underlying paper, fixate decor

Pull off the underlying paper until the middle of the decor and cut the lose paper with a pair of scissors. Flatten out the sticker by the help of a squeegee (or dough scraper) both on the inside and on the outside.

After you have done that, one part of the sticker has already been fixated. Remove the sticker and fold the non-fixated part to the middle. Remove the underlying paper carefully and fixate the remaining part of the sticker.

Step 4: Remove overhead sheet

Pull off carefully the overhead sheet from a very shallow angle. If the material of the surface or the model are sensitive, moisten the overhead sheet and let it soak briefly.

Step 5: Final steps

Only after letting the sticker dry for 48 hours at a temperature of at least 15 degrees, the stickers are properly fixated. If the temperature is lower, the sticker will need more time to congeal. Smaller blisters will disappear after a while. Larger air bubbles can be pricked carefully by the help of a needle.

andreas.brunnlechner@t-online.de

www.andys-folienwelt.de

Andreas Brunnlechner- Erlenstraße 4a, 83052 Bruckmühl

Phone: 08062/728762

INSTRUCTIONS FOR WET ADHESIVE BONDING

Step 1: Prepare surface

The surface and the room should have a temperature of at least 10 degrees. If the surface has recently been painted, make sure that the varnish is completely hard and dry.

Clean and defat the surface thoroughly. There should be no remains of wax or polish on the surface.

Our tip: If there is a wax layer on the surface, use silicon remover.

Step 2: Cut decor

Cut the decors thoroughly before fixation. If the decor consists of several parts, it is easier to cut them separately.

Hold the sticker up to the model and fixate it with tape in the middle once the sticker is in the right position.

Step 3: Remove underlying paper

Put the sticker on a level surface and flatten out the sticker.

Turn the decor around and roll down the underlying paper from a very shallow angle.

Step 4: Moistening

Moisten the relevant surface and the sticker with a sufficient amount of water.

Use a drop of dish detergent per liter if the stickers are large. (The sticker needs more time to get properly fixated with wet adhesive bonding)

Step 5: First provisional fixation

Hold the decor up to the surface and fixate it by the help of the tape. Thanks to the dish detergent between the surface and the sticker, the position of the sticker can still be changed.

Step 6: Using a squeegee

After you have found the right position, use a squeegee (or a dough scraper) to get out the water from under the sticker.

Step 7: Remove overhead sheet

Let the sticker dry a bit. Pull off carefully the overhead sheet from a very shallow angle. You might have to moisten the sheet again.

Step 8: Final steps

Only after letting the sticker dry for 48 hours at a temperature of at least 15 degrees, the stickers are properly fixated. If the temperature is lower, the sticker will need more time to congeal. Smaller blisters will disappear after a while. Larger air bubbles can be pricked carefully by the help of a needle.

andreas.brunnlechner@t-online.de

www.andys-folienwelt.de

Andreas Brunnlechner- Erlenstraße 4a, 83052 Bruckmühl

Phone: 08062/728762